



TPS MOUNTING INSTRUCTIONS FOR: S, S YOUTH, R, CPX-R, CPV-R, CS-R, CS

STEP 1

Drill the center front hole through the middle "C" in the word cas Cade or 3/8" up from bottom of chin piece using a 7/32"




STEP 3 Center Front: Follow the illustration to hook up



STEP 2

Drilling each side hole location depends on your helmet, choose your helmet below. You will need to measure from the center of the side hook-up screw to the specified location.




Parts

- 1 TPS throat piece,
- 1 short, 2 long t-nuts,
- 2 silver screws, 2 silver bushings,
- 1 black screw, 2 black bushings.


Tools Needed

Drill, 7/32" drill bit, ruler, Phillips head screwdriver, marker.



STEP 4

Side: Follow illustration to hook up the left side. Then mirror for the right. Screw head must be flush to silver spacer.



All pieces must be installed for the TPS to work properly. Make sure the TPS moves freely

up and down. Check that all 3 screws are firmly

tightened.

DO NOT USE IF THE TPS DOES NOT FREELY MOVE OR IS CRACKED

Please call us @ 1.800.537.1702 if you need assistance.

WARNING

No equipment can prevent all injuries. Lacrosse is a body contact sport. The ball moves at high speed. People get hurt and killed playing the game of lacrosse. This TPS throat piece cannot prevent all injuries to the neck, face, eyes, teeth, brain, skull and body. Some steps to reduce your risk of injury are to: follow the rules of the game, be smart, and carefully inspect all of your equipment prior to each time you go onto the field. Do not use equipment that is bent, broken, or defective.

4697 Crossroads Park Drive Liverpool, NY 13088 800.537.1702 [toll free] 315.453.3073 [cutaide USA] 315.453.3762 [fax]









TPS MOUNTING INSTRUCTIONS

S, S YOUTH, R, CPX-R, CPV-R, CS-R, CS